

Alu-Cab Canopy Camper Upper Rear Solid / MOLLE Panel

Tools required for installation:
4mm Allen Wrench, 13mm Wrench, Pencil

Hardware & L-Brackets:

Insert two bolts in the lower rail and two in the upper rail. You may need to clean out the rail slots as they may have some sealant in them from installing the Alu-Cab. Install the L-Brackets using a shim under each. Tighten down the nuts leaving enough looseness to adjust the position of the L-Brackets. Place the panel in the opening so that you can use a pencil to mark the locations of the panel holes on the rail. Once you have the location, tighten down the L-Brackets. You may need to adjust the location of each L-Bracket a few times to get it to line up with the panel.

