

MOLLE Panel - Installation Instructions

Tools required for installation: 4mm allen wrench, T-25 torx wrench

Step 1

Remove the stock panel bolts using a T-25 torx bit. Place the included nylon spacers over the hole locations.



Step 2

Using the included M6 x 50mm screws and washers, loosely tighten each screw to assure proper alignment of all holes and screws. Once all screws are in place begin to tighten. **DO NOT OVERTIGHTEN** as the stock tread inserts in the tailgate can strip if over tightened.



Step 3

Final install should look like the image to the right. Enjoy!



Included hardware:
8 - M6 x 50mm stainless screws
8 - 1" nylon spacers
8 - 1/4" stainless washers



Please let us know if you have any questions - eight13design@gmail.com