

Alu-Cab Canopy Camper VersaPlate with/without VersaPlate RotoPaX Mount

Tools required for installation:
4mm Allen Wrench, 13mm Wrench, Protective Pad for Window, Thread Lock

Hardware:

If your camper is already installed, you will need to remove the filler plate between the camper and cab. Insert four bolts in the inside top rail (under overhang) and have the two short bolts ready to install in the lower side rail. You may need to clean out the slots as they may have some sealant in them from the Alu-Cab production process.



Rubber Trim:

Your kit includes two strips of rubber trim. There are two flanges, one at the bottom of the VersaPlate and one on the side closest to the center of the camper. Apply both strips of trim before installing your VersaPlate.



Protective Mat For Rear Window:

If your Alu-Cab is already installed, we highly recommend that you use some sort of protective mat, something similar to a Yoga mat, to protect the rear window during the install.



Installing the VersaPlate:

If your Alu-Cab is already installed, you will need to first flip the VersaPlate to clear the upper corner brace. Make sure to protect your rear window before doing so. Slowly flip the VersaPlate into the upward position. Set the VersaPlate over the four bolts at the top. Install the nuts by hand so the VersaPlate stays in place while you install the two shorter bolts into the vertical edge rail. With a 13mm wrench tighten down all 6 nuts to complete the VersaPlate install.



Installing the RotoPaX Mount: Using the pre-installed Rivnuts, add thread lock to all screws. Install the lower bracket first (1). Next, install the upper bracket (2) but keep the screws loose enough to adjust the height of the upper bracket so it is snug with your RotoPaX installed. There is a supplied plate to use with a pad lock. (Pad lock not included)

